



STANDARD LEVER

Cylinder Removal



1

If lever is locked, rotate spindle to the unlocked position.



2

3


small screwdriver

STANDARD LEVER


Cylinder Replacement



1



2



3

