



KEY	114	114H	114HLW	DESCRIPTION
NO.	PART NO.	PART NO.	PART NO.	
1	001 114	001 114H	001 114HLW	Right Side Plate
2	002N114	002N114H	002N114HL	Right Side Ring
2A	003 114	003 114H	N/A	Inner Ring (2 Req)
3	003 114	003 114H	003 114HL	Bridge Assembly
3A	003 114-1	003 114H-1	003 114HL-1	Bridge Sub-Assembly
4	004 114	004 114	004 115	Fiber Drag Washer (5 req)
5	005 114	005 114	005 115	Metal Ear Washer (2 req)
6	006 114	006 114	006 115	Metal Drag Washer Set
7	007C114	007C114	007C115	Tension Spring
7C	007C114	007C115	007C115	Spacing Sleeve
8	008 114	008 114	008 114	Star Drag Wheel
8A	008 115	008 115	008 115	Eccentric Jack
9	009N114	009 114H	009 114HL	Pinion Yoke
10	010 114	010 114	010 114	Pinion
11	011 114	011 114	011 114	Dog Spring
12	012 114	012 114	012 114	Lower Bridge Screw (2 req)
13	013 114	013 114H	013 114HL	Upper Bridge Screw (2 req)
14	014 114	014 114	014 114	Clutch (Yoke) Spring (2 req)
15	015 114	015 114H	015 114HL	Spring Disc
16	016 114	016 114	016 114	Eccentric
17	017 114	017 114	017 114	Eccentric Spring
18	018 114	018 114	018 114	Eccentric Lever
18A	N/A	018 114H	018 114HL	Eccentric Screw
19	019 114	019 114	019 114	Handle Look Screw
20	020 114	020 114	020 114	Handle
21	021 114	021 114	021 114	R.S. Bearing
22	023 060	023 060	023 060	Left Side Ring
23	023 116	023 116	023 116	Left Side Ring
23A	110 060	110 060	110 060	Spool Assembly
24	024 057	024 057	024 057	Stand
26	026 114	026 114	026 116	L.S. Screw (5 req)
27	027 114	027N114H	027N114HL	Rod Clamp
28	002N114	002N114	002N114	*Ringed Rod Clamp (Optional)
28L	029L114	029L114HL	029L114HLW	Rod Clamp Screw (2 req)
30	030 114HL	030 114HL	030 114HL	Click Tongue
32	032 021	032 021	032 021	Click Button
33	033 340	033 340	033 340	+Frame Post
33*	*033R114	*033R114	*033R114	R.S. Plate Screw (5 req)
34	034 010KG	034 010KG	034 010KG	Metal Keyed Washer
35	035 114	035 114	035 114	Gear Sleeve
36	036 114H	036 114H	036 114H	Stand Screws (4 req)
36	+037M114	+037M114	N/A	Pressure Plate Washer
37M	N/A	N/A	N/A	Felt Washer
39	039 012	039 012	039 012	Rod Clamp Nut (2 req)
40	040 114	040 114HL	120 114HL	Frame
40A	N/A	120 114HL	120 114HL	
41	041 114	N/A	N/A	
54	054 114	054 114	054 114	
62	062 114	062 114	062 114	
62A	063 209	063 209	063 209	
62A	069B600	069B600	069B600	
69	069B600	069B600	069B600	
86	086 114L (4)	086 115L (3)	086 115L (3)	
98	098 114	098 114	098 114	
102	102 114	102 114	102 114	
118	118 080	118 080	118 080	
136	136 114	N/A	N/A	
140	140 114	N/A	N/A	
149	149 045	149 045	149 045	
+183	+183 114	+183 114H	183 114HLWT	

\* = Not Shown  
 + = When replacing an older frame (that uses a shield) you must also order 37M114 Frame Post.  
 N/A = Not Applicable