




PARTS LIST FOR MODEL PURSUIT 7000/8000
REEL PART NO.1190636/1190638



KEY NO.	PART NO.	DESCRIPTION
22	1204018	22-6000PUR Bail Pivot Cover Screw
24	1204072	24-7000PUR Bail Wire Assembly
24	1204073	24-8000PUR Bail Wire Assembly
27	1204074	27-7000PUR Rotor (w/weight & screw)
27	1204075	27-8000PUR Rotor (w/weight & screw)
27A	1204076	27A-7000PUR Bail Pivot Cover
28	1204077	28-7000PUR Trip Lever
28	1204078	28-8000PUR Trip Lever
31	1204039	31-6000PUR Bail Arm Screw (2 req)
32	1200520	32-6000SG Bail Spring
34	1204042	34-6000PUR Bail Arm
34C	1191656	34C-7000SG Pivot Arm
35	1203991	35-3000PUR Line Roller
35A	1203992	35A-3000PUR Line Roller Bushing
36	1203993	36-3000PUR Bail Stud Screw
38	1204084	38-7000PUR Rotor Nut
38A	1203995	38A-3000PUR Rotor Locking Plate Screw
39	1204086	39-7000PUR Spool Shaft Assembly
43	1204087	43-7000PUR Crosswind Block
43A	1191821	43A-7000SG Crosswind Block Plate
43B	1203997	43B-3000PUR Crosswind Block Plate Screw (2 req)
44	1191845	44-5000SG Crosswind Block Screw (2 req)
45	1204089	45-7000PUR Housing Cover
46	1204054	46-5000PUR Housing Cover Screw (4 req)
47	1204091	47-7000PUR Spool Complete
47	1204092	47-8000PUR Spool Complete
48	1211625	48-5000SG Click Tongue
48A	1211626	48A-5000SG Click Tongue Washer
48B	1211612	48B-5000SG Spool Click Screw
49	1211627	49-5000SG Click Tongue Spring
51	1287231	51-8000PUR Drag Retaining Ring
52	1204094	52-7000PUR Drag Knob Assembly
56	1192038	56-7000SG Drag Washer (5 req)
57	1192046	57-7000SG Keyed Washer (3 req)
58	1192055	58-7000SG Earred Washer (2 req)
60	1192062	60-5000SG Thrust Washer
95B	1192186	95B-5000SG Rotor Locking Plate
98C	1192215	98C-5000SG Clutch/Sleeve Assembly
98W	1204095	98W-7000PUR Clutch Washer
132	1192297	132-5000SG Roller Washer
132A	1192302	132A-3000SG Line Roller Washer (2 req)
231	1192507	231-7000SG Crosswind Gear
231B	1204097	231B-7000PUR Screw Crosswind Gear
231C	1204098	231C-7000PUR Screw Crosswind Sleeve
233	1204059	233-5000PUR Cover Assembly Bearing

KEY NO.	PART NO.	DESCRIPTION
1	1204060	1-7000PUR Housing
1	1204061	1-8000PUR Housing
4	1190937	4-5000SG Dog
5	1190966	5-5000SG Dog Spring
6	1190979	6-5000SG Retaining Clip
8	1204062	8-7000PUR Main Gear
8A	1204063	8A-7000PUR Shim
10	1191068	10-7000SG A/R Holder
11	1191087	11-7000SG Bushing
12	1191090	12-5000SG A/R Bushing Spring
15	1204064	15-7000PUR Handle Assembly
19	1204065	19-7000PUR Pinion
20	1204012	20-5000PUR Lower Pinion Ball Bearing
20A	1204013	20A-5000PUR Upper Pinion Ball Bearing
20B	1204068	20B-7000PUR Housing Ball Bearing
20C	1204069	20C-7000PUR Housing Cover Ball Bearing
21	1192636	21-5000SG Bearing Retainer
21A	1204016	21A-5000PUR Bearing Retainer Screw (3 req)
21B	1192650	21B-5000SG Collar