

HARDY
ALN WICK | ENGLAND

Tackling the World

Angel
Featherweight



This reel has been made by craftsmen using the best materials available to ensure its reliability. Its high quality components are precision machined with the absolute minimum susceptibility to wear or the need for future readjustment.


Given care and periodic cleaning, your reel will be a faithful servant and give you years of superb performance.

Hardy & Greys Limited, Willowburn, Alnwick,
Northumberland, NE66 2PF, England
Tel +44 (0)1665 602771 Fax +44 (0)1665 602389
www.hardyfishing.com sales@hardyfishing.com

Care and Maintenance

The same method of cleaning is valid for all reels in the freshwater Angel Reel range.

1. Remove line and backing.
2. Remove the spool.
3. Flush away dirt by placing the spool and frame under a stream of warm water.
4. Dry carefully with a lint free cloth.
5. Lubricate with a good quality oil at the points illustrated on the diagrams.
6. Always ensure the spindle head is adequately greased.
7. Always turn the click-check to the minimum setting to avoid compression of the spring.
8. Always ensure the reel and line are dry before storing in the case or pouch.




Changing your reel from left to right hand wind

All Angel reels are designed to work in right and left hand wind. When you receive your reel, it will be set for left hand wind.

To convert your reel to right hand wind:

1. Remove the spool from the frame.
2. Turn the LH tongue into the off position using your fingers.
3. Turn the RH tongue into the engaged position as shown below.
4. Re-assemble drum/plate into frame.



Angel Click-Check System

The click-check mechanism can be adjusted by simply turning the regulator button on the face of the frame, clockwise to increase the drag, anti-clockwise to decrease the check. When the reel is not in use, the check should be turned to the minimum setting.

Lifetime original user warranty

All Hardy reels carry an original owner lifetime warranty against any defect in workmanship or materials. Should there be any defect, Hardy will, at its option, repair or replace the item. This warranty does not cover damage caused by misuse, lack of maintenance, negligence or normal wear and tear. Warranty claims with the proof of purchase should be sent to the Customer service department (using the Hardy address).