

# MODEL: PFL SP SUPREME XT SUPXTSP30

ITEM	DESCRIPTION	SAP #	ITEM	DESCRIPTION	SAP #
1	DRAG KNOB ASSY	1359873	39	SCREW	1201845
2	WASHER	1359874	40	BEARING COVER	1201846
3	SCREW	1200745	41	BEARING	1224305
4	SPOOL RING	1359875	42	BEARING SLEEVE	1200863
5	KEY WASHER	1201812	43	ONE WAY CLUTCH ASSY	1223660
6	DRAG WASHER	1210734	44	CLUTCH SPRING	1200805
7	SPOOL SUB-ASSY	1360756	45	WASHER	1201852
7A	SPOOL ASSY	1360757	46	PINION GEAR	1359884
8	SPOOL CLICK	1216525	47	BUSHING	1200797
9	SPOOL SPRING	1214415	48	SCREW	1359885
10	SCREW	1216396	49	N-R CAM	1216543
11	SHEET WASHER	1201817	50	N-R LEVER SPRING	1201856
12	WASHER	1200772	51	N-R LEVER SHAFT	1201857
13	BEARING	1200773	52	SCREW	1200808
14	SLEEVE	1200774	53	N-R LEVER	1201859
15	CLICK GEAR	1216528	54	DUST CAP	1360746
16	MAIN SHAFT	1359878	55	WASHER	1201863
17	SCREW	1216538	56	BEARING	1224308
18	BAIL HOLDER	1360758	57	GEAR	1359886
19	BAIL WIRE SUB-ASSY	1360759	58	DRIVE GEAR	1360747
20	LINE ROLLER WASHER	1200780	59	GEAR WASHER	1200798
21	LINE ROLLER	1200782	60	GEAR WASHER	1200876
22	BEARING	1200781	61	BODY COVER ASSY	1360762
23	LINE ROLLER COLLAR	1201829	62	WASHER	1201870
24	SCREW	1216532	63	SCREW	1359861
25	BAIL ARM	1360760	64	SCREW	1216637
26	SCREW	1200786	65	HANDLE ASSY	1360763
27	SCREW	1216534	66	SCREW	1201875
28	ROTOR COVER	1359882	67	O/S SLIDER	1201874
29	BAIL SPRING	1201835	68	SCREW	1220375
30	BAIL ARM GUIDE	1201836	69	O/S GEAR BUSHING	1216641
31	TRIP PLUNGER	1201837	70	O/S GEAR	1216642
32	ROTOR SLEEVE	1270829	71	BEARING	1216643
33	ROTOR	1360761	72	SCREW	1201877
34	SCREW	1201840	73	O/S SLIDER PLATE	1201876
35	ROTOR NUT RETAINER	1201841	74	SCREW	1205959
36	ROTOR NUT	1201842	75	REAR COVER	1359889
37	BUSHING	1205927	76	BODY ASSY	1360764
38	CLUTCH WASHER	1216633			

## EXPLODED VIEW

