

MODEL: PFL SP PRESIDENT 6935

ITEM	DESCRIPTION	SAP #		ITEM	DESCRIPTION	SAP #
1	DRAG KNOB ASSY	1248979		37	CLUTCH WASHER	1205956
3	STOP RING	1262749		38	SCREW	1200799
4	KEY WASHER	1201739		39	BEARING COVER	1200800
5	DRAG WASHER	1208974		40	BEARING	1200862
6	EARED WASHER	1205941		41	BEARING SLEEVE	1201777
8	SPOOL SUB-ASSY	1262750		42	WASHER	1205969
8A	COMPLETE SPOOL VENTED	1262751		43	ONE WAY CLUTCH	1200803
9	SPOOL CLICK	1216395		44	CLUTCH SPRING	1224307
10	SPOOL SPRING	1214415		45	PINION GEAR	1203280
11	SCREW	1216404		46	BUSHING	1210765
12	SHEET WASHER	1201745		47	N-R LEVER SPRING	1200806
13	WASHER	1200833		48	N-R LEVER SHAFT	1200870
14	BEARING	1200773		49	SCREW	1205959
15	SLEEVE	1200835		50	N-R LEVER	1209709
16	CLICK GEAR	1201749		51	DUST CAP ASSY	1248985
17	MAIN SHAFT	1224197		52	BEARING	1200874
18	SCREW	1200784		53	DRIVE GEAR	1205930
19	BAIL HOLDER	1248982		54	GEAR WASHER	1200798
20	BAIL WIRE SUB-ASSY	1206618		55	GEAR WASHER	1200876
21	WASHER	1200780		56	GEAR WASHER	1200878
22	LINE ROLLER	1200782		57	BODY COVER ASSY	1248986
23	BEARING	1200781		58	SCREW	1200816
24	LINE ROLLER COLLAR	1201757		59	SCREW	1210701
25	BAIL ARM	1220137		60	HANDLE ASSY	1248987
26	SCREW	1205887		61	SCREW	1200819
27	SCREW	1200787		62	O/S SLIDER	1216583
28	ROTOR COVER	1248983		63	SCREW	1248988
29	BAIL SPRING	1200850		64	O/S GEAR BUSHING	1216641
30	BAIL ARM GUIDE	1200851		65	O/S GEAR ASSY	1241392
31	TRIP PLUNGER	1205953		66	BEARING	1216643
32	ROTOR SUB-ASSY	1248984		67	SCREW	1205909
33	SCREW	1200794		68	O/S SLIDER PLATE	1205972
34	ROTOR NUT RETAINER	1200795		69	INNER COVER	1248989
35	ROTOR NUT	1200857		70	REAR COVER	1248990
36	BUSHING	1210765		71	BODY ASSY	1248991

EXPLODED VIEW

