

MODEL : PFL SP PRESIDENT 6940

ITEM	DESCRIPTION	SAP #	ITEM	DESCRIPTION	SAP #
1	DRAG KNOB ASSY	1248979	37	CLUTCH WASHER	1205956
3	STOP RING	1262749	38	SCREW	1200799
4	KEY WASHER	1201739	39	BEARING COVER	1200800
5	DRAG WASHER	1208974	40	BEARING	1200862
6	EARED WASHER	1205941	41	BEARING SLEEVE	1201777
8	SPOOL SUB-ASSY	1262752	42	WASHER	1205969
8A	COMPLETE SPOOL VENTED	1262753	43	ONE WAY CLUTCH	1200803
9	SPOOL CLICK	1216395	44	CLUTCH SPRING	1224307
10	SPOOL SPRING	1214415	45	PINION GEAR	1203280
11	SCREW	1216404	46	BUSHING	1210765
12	SHEET WASHER	1201745	47	N-R LEVER SPRING	1200806
13	WASHER	1200833	48	N-R LEVER SHAFT	1200870
14	BEARING	1200773	49	SCREW	1205959
15	SLEEVE	1200835	50	N-R LEVER	1209709
16	CLICK GEAR	1201749	51	DUST CAP ASSY	1248985
17	MAIN SHAFT	1248875	52	BEARING	1200874
18	SCREW	1200784	53	DRIVE GEAR	1205930
19	BAIL HOLDER	1248982	54	GEAR WASHER	1200798
20	BAIL WIRE SUB-ASSY	1206628	55	GEAR WASHER	1200876
21	WASHER	1200780	56	GEAR WASHER	1200878
22	LINE ROLLER	1200782	57	BODY COVER ASSY	1248986
23	BEARING	1200781	58	SCREW	1200816
24	LINE ROLLER COLLAR	1201757	59	SCREW	1210701
25	BAIL ARM	1220137	60	HANDLE ASSY	1248987
26	SCREW	1205887	61	SCREW	1200819
27	SCREW	1200787	62	O/S SLIDER	1216583
28	ROTOR COVER	1248876	63	SCREW	1248988
29	BAIL SPRING	1200850	64	O/S GEAR BUSHING	1216641
30	BAIL ARM GUIDE	1200851	65	O/S GEAR ASSY	1241390
31	TRIP PLUNGER	1206629	66	BEARING	1216643
32	ROTOR SUB-ASSY	1248877	67	SCREW	1205909
33	SCREW	1200794	68	O/S SLIDER PLATE	1205972
34	ROTOR NUT RETAINER	1200795	69	INNER COVER	1248989
35	ROTOR NUT	1200857	70	REAR COVER	1248990
36	BUSHING	1210765	71	BODY ASSY	1248878

EXPLODED VIEW

