












(Drawn to Scale)

(Not Drawn to Scale)



Hunter


Using this Parts Guide, make sure all parts are included in the box.

If parts are missing, DO NOT RETURN

THIS ITEM TO THE STORE, call 888-830-1326 for assistance.

THIS PARTS GUIDE IS FOR REFERENCE ONLY.

REFER TO THE INSTALLATION MANUAL FOR FULL ASSEMBLY INSTRUCTIONS.



Parts List

Parts List	Model #	23863
	Asm. Dwg. #	G2674-01
	Finish	Black
Item Name	Qty	Part #
Canopy Assembly	1	G2688-02
Setscrew	1	03009-04
Mounting Bracket	1	G2687-02
Rubber Bushing and Pin	1	G2686-02
Screw, Lag	1	03481-04
Hanger Pipe	1	73523-09
U-Bracket	1	G2685-02
Hardware Kit	1	K3992-06-000
Screw, Blade Iron Armature		
Blade Grommet		
Blade Assembly Screw		
Wire Connector		
Switch Housing Cover	1	G2681-01
Blade Iron Set	1	92523-05
Blade Set	1	K4745-25-205
Oil Tube	1	07561-03
Light Kit Adapter	1	G2789-01
Balancing Kit	1	K0118-01
Pull Chain Extension	1	K0139-06

