

IMPORTANT NOTE

ABOUT DC FAN MOTOR OPERATION

You may notice a short delay and calibrating motion at startup. This is due to the fan's microprocessor control system that calculates blade conditions.

Both are normal signs of this fan's operation.

NOTE: The blades must be installed before attempting to operate the fan. If the blades are not installed, the motor will not function properly.

