


Item: MALB4C

Assembly Instructions





Please visit our website for the most current instructions, assembly tips, to report damage or request parts. www.walkeredison.com


Revised 08/23-V-1

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A hammer and a Phillips head screwdriver are required for the assembly of this product.



- VI. Power tools should not be used to assemble this product.











Parts List



Part #	Description	Qty
1	Top panel	01 pcs
2	Right side panel	01 pcs
3	Left side panel	01 pcs
4	Rail	01 pcs
5	Bottom panel	01 pcs
6	Back panel	01 pcs
7	Bottom frame	01 pcs
8	Foot	04 pcs
9	Drawer front	01 pcs
10	Drawer back	01 pcs
11	Drawer side	02 pcs
12	Drawer bottom	01 pcs

Hardware List

A		ø8*30mm	Wooden dowel	18 pcs
B		ø15*30mm	Cam Bolt	14pcs
C		ø3,5*14mm	Screw	06 pcs
D		ø15*10mm	Cam Lock	14 pcs
E		ø7*50mm	Bolt	04 pcs
F		ø3,0*12mm	Screw	08 pcs
G		ø8*8mm	Nail	18 pcs
H		ø3,5*25mm	Screw	16 pcs
I		212*36mm	Drawer handle	01 pcs
J			Hex Key	01 pc
K		250mm	Slide	02 pcs




Hammer recommended
for assembly (not included)



Philips head screwdriver required
for assembly (not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wood dowel (A) into parts 2, 3, 4, 5, 7 and 8.
Fix the Cam Bolt (B) in parts 1, 2 and 3 using a Phillips screwdriver.

A	 ø8*30mm	18
B	 Cam Bolt	14


Step 2

Separate parts (K) by pressing the down button





Secure the external slide (K) in part 2 and 3 with the screw (C) using Phillips screwdriver.

Step 3



Secure parts 4 and 5 to part 2 with Cam lock (D) using Phillips screwdriver.



Step 4



Secure parts 4 and 5 to part 3 with Cam lock (D) using Phillips screwdriver.

D		04
Cam Lock		


Step 5




Secure part 1 to parts 2 and 3 with Cam lock (D) using Phillips screwdriver.

D		06
Cam Lock		


Step 6




Secure parts 8 to part 7 with Bolt (E) using Hex key (J)





Step 7




Secure part 7 to part 5 with Screw (H) using Phillips screwdriver.







Step 8



Secure part 6 to parts 1,2,3 and 5 with Nail (G) using hammer.

G		Nail	18
---	---	------	----

Step 9






1. Secure Drawer side 11 to Drawer front 9 with screw (H) using Phillips screwdriver.

2. Slide part 12 into the grooves between parts 11.




3. Secure Drawer back 10 with screw (H) using Phillips screwdriver.

H		Screw 3,5x25mm	08
---	---	----------------	----




Step 10



Secure Drawer handle (I) to drawer front 9 with screw (F) using Phillips screwdriver.
Secure Inner slide (K) to drawers sides 11 with screw (F) using Phillips screwdriver.

F	 Screw 3,0x12mm	08
I	 Drawer handle	01
K	 inner slide	02

Step 11



To pull out your drawer pressing the down button.

 Walker Edison®