CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from sratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening
- * This item may require a pair of pliers to unscrew the screws to a suitable length during assembly when feet are too short to fit into the item.

Part List


PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Table Top		1X
В	Leg	-(4X
С	Bottom Board		1X
D	Foot		4X



Item# AMH5704

Product Dimensions:17.75" W x 13.75" D x 32" H

Weight Capacity: 40LBS






Warning: Do not stand on the Table Warning: Do not over torque bolts.


PREPARATION


Step 1

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 5 minutes.

Step 2







Take all packaging off the accent table. Screw four legs to the table top and gently tighten the legs.

Put the bottom shelf over the end of four legs, make sure the holes on shelf are lined with the holes on legs.

Step 3

Slightly screw four feet through bottom shelf to connect with legs. Turn the table up to right side, adjust the legs and feet to make it stable.