


CROSLEY




FURNITURE

Coffee Table





CF1341




PART LIST

#A 	#B 	#C 	#D 	#E 
Table Top 1 PC	Leg 2 PCS	Leg Support 1 PC	Pedestal Support 1 PC	Table Support 4 PCS


HARDWARE LIST

#1  5/16"	#2  5/16"	#3  5/16"x22	#4  12.8mm	#5  M6 x 50mm
Hex Nut 6 PCS (Extra 1)	Spring Washer 6 PCS (Extra 1)	Flat Washer 6 PCS (Extra 1)	Wrench 1 PC	Bolt 9 PCS (Extra 1)
#6  1/4"	#7  M6 x 13mm	#8  M4		
Small Spring Washer 9 PCS (Extra 1)	Small Flat Washer 9 PCS (Extra 1)	Allen Wrench 1 PC		


Step 1. Attach pedestal support (part D) to legs (part B) using flat washers (part #3), spring washers (part #2), hex nuts (part #1) and wrench (part #4).



Step 2. Attach table supports (part E) to legs (part B) using flat washers (part #3), spring washers (part #2), hex nuts (part #1) and wrench (part #4).




Step 3. Lay assembled unit (parts B, D & E) upside down on soft surface, such as carpet.
Attach leg support (part C) to legs (part B) using bolts (part #5), small spring washers (part #6), small flat washers (part #7) and allen wrench (part #8).




- #5  x 2
- #6  x 2
- #7  x 2
- #8  x 1

Step 4. Attach assembled unit (parts B, D & E) to table top (part A) using bolts (part #5), small spring washers (part #6), small flat washers (part #7) and allen wrench (part #8).



- #5  x 7
- #6  x 7
- #7  x 7
- #8  x 1

Step 5. Carefully turn assembled unit upright.



Note: It is important to adjust levelers once fully assembled and upright.
Extend adjustable leveler until it's firmly in contact with the floor.
If relocating, adjust leveler as needed until it's firmly in contact with
the floor in new location.