




PARTS LIST FOR MODELS 113H2 (1153838), 113H2LW (1153841), AND 113H2SP (1153840)



<u>KEY NO.</u>	<u>113H2 PART NO.</u>	<u>113H2LW PART NO.</u>	<u>113H2SP PART NO.</u>	<u>DESCRIPTION</u>	<u>KEY NO.</u>	<u>113H2 PART NO.</u>	<u>113H2LW PART NO.</u>	<u>113H2SP PART NO.</u>	<u>DESCRIPTION</u>
1	1197481	1197481	1197481	1-113H2 Right Side Plate	27	1197521	1197521	1197521	27-113H2 Left Side Plate
2	1197489	1197489	1197489	2-113H2O Outer Right Side Ring	28	1197488	1197488	1197488	2-113H2I Inner Side Ring (2 req.)
3	1197495	1197495	1197495	3-113H2 Bridge Assembly	28A	1197527	1197527	1197527	28-113H2 Outer Left Side Ring
4	1180775	1180775	1180775	4-349 Fiber Washer	29	1191514	1191516	1191515	29-113H2, H2W, H2SP Spool
5	1180843	1180843	1180843	5-113H Main Gear	32	1182708	1182708	1182708	32-15 Handle Nut Cap Screw
6	1180909	1180909	1180909	6-113H Drag Washer (5 req.)	33	1182754	1182754	1182754	33-113 Rod Clamp
7	1181029	1181029	1181029	7-970 Metal Ear Drag Washer (2 req.)	33C	1197533	1197533	1197533	33C-112H2 Rod Clamp Kit
7C	1197506	1197506	1197506	7C-113H2 Metal Drag Washer Set	*	*1182783	*1182783	*1182783	*33R-200 Ringed Rod Clamp (Optional)
8	1181077	1181077	1181077	8-349Tension Spring	34	1182786	1182786	1182786	34-016VS Clamp Screw (2 req.)
8A	1181627	1181627	1181627	18-970 Tension Spring	35	1182901	1182901	1182901	35-060 Click Tongue
9	1197507	1197507	1197507	9-113H2 Spacing Sleeve	36	1182989	1182989	1182989	36-113 Click Button
10	1181197	1181197	1181197	10-349 Star Drag Wheel	37	1183066	1183067	1183066	37-113, 113HLW Frame Post (2 req.)
11	1181233	1181233	1181233	11-113 Eccentric Jack	39	1197540	1197540	1197540	39-112H Side Plate Screw (10 req.)
12	1181257	1181257	1181257	12-60 Pinion Yoke	40	1197542	1197542	1197542	40N-113HL Left Side Bearing Assembly
13	1181317	1181317	1181317	13-113H Pinion	40A	1184522	1184522	1184522	120-113H Left Side Bearing O-Ring
14	1181393	1181393	1181393	14-99 Dog Spring	54	1183856	1183856	1183856	54-113 Harness Lug (2 req.)
15	1181435	1181435	1181435	15-113H Dog	55	1183880	1183880	1183880	55-113H Right Side Bearing
16	1181570	1181570	1181570	16-113H Lower Bridge Screw (2 req.)	62	1184028	1184028	1184028	62-309 Click Spring
17	1181595	1181595	1181595	17-113H Upper Bridge Screw (2 req.)	62A	1184048	1184048	1184048	63-209 Click Spring Screw
18	1181615	1181615	1181615	18-60 Clutch Spring (2 req.)	69	1184129	1184129	1184129	69B-600 Retaining Ring
19	1181662	1181662	1181662	19-113 Eccentric	86	1184253	1184253	1184253	86-113H Metal Keyed Drag Washer
20	1288917	1288917	1288917	20-113H2 Eccentric Spring	86A	1184270	1184270	1184270	86-970 Metal Keyed Drag Washer (2 req.)
21	1181835	1181835	1181835	21-66 Eccentric Lever	98	1197430	1197430	1197430	98-113H Gear Sleeve
22	1197513	1197513	1197513	22-112H2 Eccentric Screw	102	1192230	1192230	1192230	102-113 Gear Sleeve Pin
23	1181950	1181950	1181950	23-555 Handle Nut	110A	1184442	1184442	1184442	110A-555 Handle Nut Cap
24	1197517	1197517	1197517	24-113H2 Handle Assembly	149	1184702	1184702	1184702	149-045 Clamp Nut (2 req.)
					149A	1184706	1184706	1184706	149-200 Hex Nut (2 req.)
					183	1198906	1198939	1198908	183N-113HL, HLW, HSP Frame Asm.

*Not Shown