


PENN[®] PARTS LIST FOR MODEL 113L2



KEY

NO.	DESCRIPTION
1	1-113L2 Right Side Plate
2	2-113H2I Inner Ring (2 req)
3	3-113L2 Bridge Assembly
4	4-60 Fiber Washer
5	5-66 Main Gear
6	6-113 Drag Washer (3 req)
7	7-60 Metal Ear Drag Washer
7C	7C-60 Metal Drag Washer Set
8	8-60 Spring Washer (3 req)
9	9-66 Spacing Sleeve
10	10-113L2 Star Drag Wheel
11	11-113 Eccentric Jack
12	12-113 Pinion Yoke
13	13-113 Pinion
14	14-99 Dog Spring
15	15-99 Dog
16	16-60CH Lower Bridge Screw (2 req)
17	17-60CH Upper Bridge Screw (2 req)
18	18-60 Yoke Spring (2 req)
19	19-113 Eccentric
20	20-113H2 Eccentric Spring
21	21-66 Eccentric Lever
22	22-112H2 Eccentric Screw
23	23-555 Handle Nut
24	24-113L2 Handle Assembly

PART

NO.	
1197482	
1197488	
1197498	
1180755	
1180828	
1180908	
1181007	
1181041	
1181056	
1181148	
1197511	
1181233	
1181260	
1181316	
1181393	
1181427	
1181565	
1181594	
1181615	
1181662	
1288917	
1181835	
1197513	
1181950	
1197518	

KEY

NO.	DESCRIPTION
27	27-113L2 Left Side Plate Assembly
28	28-113H2 Outer Ring (2 req)
29	29-113H2 Spool
32	32-15 Handle Nut Cap Screw
33	33-113 Rod Clamp
33C	33C-112H2 Rod Clamp Kit
*	*33R-200 Ringed Rod Clamp (Opt.)
34	34-16VS Clamp Screw (2 req.)
35	35-60 Click Tongue
36	36-113 Click Button
37	37-113 Frame Post (2 req)
39	39-112H Side Plate Screw (10 req)
40	40N-113HL L.S. Bearing Cup Asm
40A	120-113H Bearing Cup O-Ring
54	54-113 Harness Lug (2 req)
55	55-113H R.S. Bearing
62	62-309 Click Spring
62A	63-209 Click Spring Screw
69	69B-600 Click Retaining Ring
86	86-60 Metal Keyed Drag Washer (2 req)
98	98-112H Gear Sleeve
102	102-60 Gear Sleeve Pin
110A	110A-555 Handle Nut Cap
149	149-45 Rod Clamp Nut (2 req)
149A	149-200 Hex Nut (2 req)
183	183-113L2 Frame Assembly

PART

NO.	
1197522	
1197527	
1191514	
1182708	
1182754	
1197533	
*1182783	
1182786	
1182901	
1182989	
1183066	
1197540	
1197542	
1184522	
1183856	
1183880	
1184028	
1184048	
1184129	
1184252	
1198890	
1184408	
1184442	
1184702	
1184706	
1198900	

* Not Shown