



KEY NO.	PART NO.	DESCRIPTION
1	1195551	1-7000CQ Housing
1A	1195555	1A-7000CQ Housing Plate
8	1195559	8-7000CQ Main Gear
8A	1195562	8A-7000CQ Shim
15	1195565	15-7000CQ Handle Assembly
19	1195569	19-7000CQ Pinion
20	1181789	20-6500 Ball Bearing(4 Req.)
20A	1195570	20A-5000CQ Ball Bearing
21	1192640	21-760 Bearing Retainer
21A	1195572	21A-2000CQ Screw(3 Req.)
21B	1195574	21B-7000CQ Collar
22	1195575	22-2000CQ Screw(2 Req.)
24	1195578	24-7000CQ Bail Wire
25	1195922	25-5000CQ Bail Cam
25A	1195591	25A-2000CQ O-Ring
25B	1195592	25B-2000CQ Clip
27	1195596	27-7000CQ Rotor
27A	1195600	27A-7000CQ Bail Pivot Cover
28	1195604	28-7000CQ Trip Lever
28D	1195607	28D-7000CQ Friction Ring
28E	1195610	28E-7000CQ Friction Ring Cover
28S	1195611	28S-2000CQ Screw(2 Req.)
31	1195612	31-2000CQ Screw(2 Req.)
32	1195614	32-5000CQ Bail Spring
34	1195616	34-5000CQ Bail Arm
34B	1195618	34B-5000CQ Pivot Lever
34C	1195619	34C-2000CQ Pivot Arm
35	1195621	35-5000CQ Line Roller
35A	1195641	35A-2000CQ Ball Bearing(4 Req.)
36	1195642	36-2000CQ Screw
38	1195645	38-7000CQ Rotor Nut
38A	1195646	38A-2000CQ Screw
39	1195650	39-7000CQ Spool Shaft
43	1195654	43-7000CQ Crosswind Block
43A	1195658	43A-7000CQ Crosswind Block Pins(2 Req.)
44	1195659	44-2000CQ Screw
45	1195663	45-7000CQ Maintenance Hatch
46	1195664	46-2000CQ Screw
46A	1195666	46A-7000CQ Screw
46B	1222226	46B- 2000CQ Washer(3 Req.)
46S	1195673	46S-2000CQ Spring
47	1195679	47-7000CQ Spool Assembly
47P	1197236	47P- 7000CQ Spool
47B	1195687	47B-7000CQ Spool Band
47C	1195691	47C-7000CQ Spool Lip Cover
47D	1195692	47D-2000CQ Line Clip
47E	1195696	47E-7000CQ Line Clip Spring
47L	1195702	47L-7000CQ Spool Lip
48	1195704	48-7000CQ Spool Click
48A	1195707	48A-7000CQ Spool Click Retainer
48B	1195711	48B-7000CQ Spool Click Housing
48D	1195715	48D-7000CQ Spacer Ring
48E	1195719	48E-7000CQ O-Ring
48F	1251982	48F-7000CQ Clip
51A	1195720	51A-2000CQ Screw(12 Req.)
52	1195726	52-7000CQ Drag Knob Assembly
56	1195736	56-7000CQ Washer HT-100(4 Req.)
57	1195744	57-7000CQ Keyed Washer(3 Req.)
58	1195747	58-7000CQ Earred Washer
58A	1195750	58A-7000CQ Earred Washer
60	1195753	60-7000CQ Spacer Washer
60A	1195756	60A-7000CQ O-Ring
60C	1195760	60C-7000CQ Bearing Sleeve
60S	1195762	60S-7000CQ Seal
60W	1195765	60W-7000CQ Spool Shaft Washer
64	1195769	64-7000CQ Idler Gear
95B	1195771	95B-7000CQ Rotor Locking Plate
98C	1195775	98C-7000CQ Clutch/Sleeve Assembly
132A	1195778	132A-2000CQ Spacer(2 Req.)
226	1195788	226-7000CQ Rear Cover
227	1195798	227-7000CQ Cam Cover
231	1195810	231- 7000CQ Crosswind Gear
231B	1195812	231B-2000CQ Screw
232	1195819	232-7000 CQ Bearing Retainer(2 Req)
233	1195827	233-7000CQ Bearing Cover
233S	1257635	233S-2000CQ O-Ring