




**PARTS LIST FOR WAR30LWLCLH**  
REEL ASM. Nos. 1366199



KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
1	1405745	1-WAR30LWLCLH	Right Side Plate
1A	1383100	1A-WAR15LWLCLH	Line Counter Cover
1B	1383084	1B-WAR15LWLC	Screw, L.C.Cover(3req)
2	1405746	2-WAR30LWLCLH	Right Side Ring
3	1384179	3-WAR15LW	Bridge
4	1382976	4-WAR15LW	Drag Washer
5	1406059	5-WAR30LWLH	Main Gear
6	1382978	6-WAR15LW	Tabbed Drag Washer(2 req)
7	1382999	7-WAR15LW	Keyed Metal Drag Washer
7H	1383000	7H-WAR15LW	Heavy Metal Drag Washer
8	1383001	8-WAR15LW	Spring Washer (4 req)
9	1384180	9-WAR15LW	Spacing Sleeve
10	1383091	10-WAR15LWLH	Star Drag
10A	1383003	10A-WAR15LW	Star Click Retainer
10B	1383004	10B-WAR15LW	Star Click Washer
10C	1383005	10C-WAR15LW	Star Click Spring
11	1405741	11-WAR30LWLH	Eccentric Jack
12	1383007	12-WAR15LW	Pinion Yoke
13	1406060	13-WAR30LWLH	Pinion
15	1383009	15-WAR15LW	Anti Reverse Dog(2 req)
16	1383010	16-WAR15LW	Screw (2 req)
18	1383011	18-WAR15LW	Pinion Yoke Spring (2 req)
19	1383012	19-WAR15LW	Eccentric
20	1446771	20-WAR15LWLH	Eccentric Spring
21	1383106	21-WAR30LW	Eccentric Lever
22	1383015	22-WAR15LW	Eccentric Screw
23	1383016	23-WAR15LW	Handle Assembly Screw
23A	1383017	23A-WAR15LW	Handle Lock Screw
23B	1383018	23B-WAR15LW	Handle Screw Washer
24	1383019	24-WAR15LW	Handle Assembly
24A	1383020	24A-WAR15LW	Handle Thrust Washer
26	1383021	26-WAR15LW	Spool Tension Control Cap
26A	1383022	26A-WAR15LW	Bushing(2req)
26B	1383023	26B-WAR15LW	Clutch Retainer
26C	1383024	26C-WAR15LW	Screw(2req)
27	1405747	27-WAR30LWLCLH	Left Side Plate
27A	1446772	27A-WAR30LW	Bearing Housing
27B	1383028	27B-WAR15LW	Screw(2req)
27C	1383029	27C-WAR15LW	Screw
28	1383285	28-WAR30LW	Left Side Ring
29	1383286	29-WAR30LW	Spool
29A	1451532	29A-WAR15LW	Pin
29L	1383287	29L-WAR30LW	Spool Assembly
33	1182754	33-113	Rod Clamp

KEY NO.	PART NO.	PENN STYLE NO.	DESCRIPTION
34	1182788	34-045	Screw (2 req)
35	1383037	35-WAR15LW	Click Tongue
36	1383038	36-WAR15LW	Click Button
38	1383039	38-WAR15LW	Screw (8 req)
40	1451534	40-WAR30LW	Ball Bearing
40A	1446773	40A-WAR30LW	Washer
40B	1383044	40B-WAR15LW	Felt Washer
40C	1383045	40C-WAR15LW	Washer, Acetal Thrust
40D	1383046	40D-WAR15LW	Washer, Rubber Thrust
40E	1383047	40E-WAR15LW	Thrust Washer (2req)
41A	1384181	41A-WAR15LW	Bushing
42	1406061	42-WAR30LWLC	Worm Shaft Assembly
42A	1405737	42A-WAR30LWLC	Gear, L.C. Drive
43	1383051	43-WAR15LW	Worm Shaft Bushing(2req)
46	1383288	46-WAR30LW	Line Guide Assembly
47	1383053	47-WAR15LW	Line Guide Pawl
47A	1383054	47A-WAR15LW	Pawl Shim
48	1383055	48-WAR15LW	Line Guide Nut
50	1383057	50-WAR20LW	Worm Shield
55	1451533	55-WAR15LW	Ball Bearing
58	1383059	58-WAR20LW	Line Guide Post
60	1383060	60-WAR15LW	Worm Shaft Washer(2req)
62	1383061	62-WAR15LW	Spring
64	1383289	64-WAR30LW	Idler Gear
66	1383290	66-WAR30LW	Click Ratchet
66A	1383064	66A-WAR15LW	Spool Gear
69	1446770	69-WAR15LWLC	Retainer Ring
69A	1383066	69A-WAR15LW	Retainer Ring (2 req)
98	1383094	98-WAR15LWLH	Main Gear Shaft
98A	1383068	98A-WAR15LW	Clutch Housing
98B	1384182	98B-WAR15LW	Clutch
98R	1383069	98R-WAR15LW	Anti Reverse Ratchet
98S	1383070	98S-WAR15LW	Clutch Sleeve
120	1383071	120-WAR15LW	O-Ring
134A	1383072	134A-WAR15LW	Clutch Recover Plate
134B	1383073	134B-WAR15LW	Clutch Recover Support Plate
134C	1383074	134C-WAR15LW	Clutch Recover Spring
149	1184702	149-045	Rod Clamp Nut (2 req)
149A	1184706	149-200	Hex Nut (2 req)
154	1383077	154-WAR15LW	Click Button Washer
158	1383078	158-WAR15LW	Dog Pin(2req)
183	1405743	183-WAR30LWLH	Frame Assembly
303	1446775	303-WAR30LWLCLH	Counter Wheel Assembly